



If you receive a signal from **"DANGER BEACON"**.
Lights will **BLINK YELLOW. ALARM IS ON.**
CONFIRM WITH **OK/QUIT BUTTON** AND REDUCE
SPEED TO TAKE EXTRA CAUTION.